

Appliance Instructions – 2 & 3 Bedroom Apartments

AIR CONDITIONER/HEATER

The reverse cycle air conditioner has an indoor delivery unit and an external compressor unit. The units may take 5 – 10 minutes to heat or cool and do not deliver their full flow of air until they reach the required temperature. The external compressor may cause machinery vibrations that offend sensitive sleepers. Guest are accordingly requested to avoid running the unit overnight.

RANGEHOOD

To operate the rangehood slide the silver frontage above the hob towards you until the extractor fan and light are enabled.

DISH WASHING MACHINE

Please check that dishes and cutlery are securely loaded not to interfere with the moving rotor.

Please use only the solid dishwashing detergent pellets as supplied with built in rinse aid.

Wash cycles: Intensive 2 hrs 33 min, Universal Plus 2 hrs 17 min, Universal 1 hrs 56 min,

Light 1 hrs 24 min, Economy 2 hrs 22 min, Pre-Wash 11 min.

Please ensure any dishes remaining in the machine are pre-washed before departure.

LAUNDRY WASHING MACHINE

Please check that the lint collector is clean before each load. Withdraw the lint filter assemble from the agitator base.

Please do NOT overfill machine.

Select water level options and wash temperature before dialling wash type, and setting wash operation.

TUMBLE DRYER

Please check that the lint collector is clean before starting each load.

Please do NOT overfill dryer.

SPA

Operation is with an air switch: - Press once for ON –Press again for OFF.

Fill spa initially to above jet level before pump is switched on.

Please do not overfill.

To avoid flooding please allow for water to be displaced by people entering the bath.

The spa pump contains a heater that provides sufficient heat to keep the water warm.

The rings around each jet should initially be set **anticlockwise** and then used to adjust the water flow.

CLOCK RADIO

To set the correct **time/alarm**, depress the **time set/alarm** button and then:

(a) depress the **hour set** button, release the hour set button approximately before the set time is reached and make final adjustments with single depressions of the button.

(b) depress the **minute time set** button and set the readout to the required time.

Radio operation:- Slide the AUTO/OFF/ON switch to ON position. Select desired band with the band switch. Turn the volume control to desired volume. Turn the tuning control to select favourite station. Slide switch to AUTO for automatic alarm operation.

MICROWAVE OVEN

Set to required settings and press start.

ELECTRIC KETTLE / JUG

Fill the kettle through the pouring spout. (Do not attempt to remove the cover)

Plug the kettle into the power and switch on at the plug and also at the jug.

When the jug boils the heater power will automatically switch off at the jug but the connecting cable/cord remains live to electric power.

DVD PLAYER

The DVD player is accessible by selecting the Source button on the TV remote control and selecting AV1.

IRON & IRONING BOARD

An iron and ironing board are located in the second bedroom wardrobe in each Suite.

Appliance Instructions - Studios & 1 Bedroom Apartments

AIR CONDITIONER/HEATER

Air conditioner operation is controlled with an ON/OFF switch.

The air conditioner is set to AUTO and will sense whether it is required to heat or cool. Please do not adjust the temperature settings. Fan speed may be controlled with the fan control button.

CLOCK RADIO

To set the correct **time/alarm**, depress the **time set/alarm** button and then:

(a) depress the **hour set** button, release the hour set button approximately before the set time is reached and make final adjustments with single depressions of the button.

(b) depress the **minute time set** button and set the readout to the required time.

Radio operation: Slide the AUTO/ON/OFF switch to ON position. Select desired band with the band switch. Turn the volume control to desired volume. Turn the tuning control to select your favourite station. Slide switch to AUTO for automatic alarm operation.

ELECTRIC KETTLES AND JUGS

Fill the kettle through the pouring spout. (Do not attempt to remove the cover)

Plug the kettle into the power and switch on at both the plug and the jug.

When the jug boils the heater power will automatically switch off at the jug but the connecting cable/cord remains live to electric power.

SPA

The spa is operated by an air switch: - PRESS once for ON. PRESS again for OFF.

It should be filled to above the jet level before switching the pump on.

Please do not overfill.

To avoid flooding please allow for the water to be displaced by people entering the bath.

The spa pump contains a heater that provides sufficient heat to keep the water warm.

The rings around each jet should initially be set anticlockwise and then used to adjust the water flow.

Appliance Instructions - Rooms

AIR CONDITIONER/HEATER

Air conditioner operation is controlled with an ON/OFF switch. Select HEAT/COLD as preferred.

CLOCK RADIO

To set the correct **time/alarm**, depress the **time set/alarm** button and then:

(a) depress the **hour set** button, release the hour set button approximately before the set time is reached and make final adjustments with single depressions of the button.

(b) depress the **minute time set** button and set the readout to the required time.

Radio operation: Slide the AUTO/ON/OFF switch to ON position. Select desired band with the band switch. Turn the volume control to desired volume. Turn the tuning control to select your favourite station. Slide switch to AUTO for automatic alarm operation.

ELECTRIC KETTLES AND JUGS

Fill the kettle through the pouring spout. (Do not attempt to remove the cover)

Plug the kettle into the power and switch on at both the plug and the jug.

When the jug boils the heater power will automatically switch off at the jug but the connecting cable/cord remains live to electric power.

REFRIGERATOR

Where the refrigerator is in a cupboard it may be necessary to leave the cupboard door slightly open in the really hot weather to allow the heat removed from refrigerated goods to be dispersed.